



SCK GND
 TP44 TP45
 R40 TP48
 3V8 TP40 PWDN

SDA0 TP46
 SCL0 47 Cam_VDD

USB_ON/OFF

CLK2 DAT2
 TP18 TP19



TP49 SD_VDD



SD 2.0

